



REOVIB

Control Equipment for the Vibratory Feeder Industry

MFS 268 (6217)

**400 V, 8/16 A Panel mounting construction
115/230 V, 32 A Panel mounting construction**

Frequency Converter for Vibratory Feeders

Technical safety instructions for the user

This description contains the necessary information for the correct application of the product described below. It is intended for use by technically qualified personal.

Qualified personnel are persons who, because of their training, experience and position as well as their knowledge of appropriate standards, regulations, health and safety requirements and working conditions, are authorised to be responsible for the safety of the equipment, at all times, whilst carrying out their normal duties and are therefore aware of, and can report, possible hazards (Definition of qualified employees according to IEC 364)

Safety Instructions

The following instructions are provided for the personal safety of operators and also for the protection of the described product and connected equipment.



Warning!
Hazardous Voltage
Failure to observe can kill, cause serious injury or damage

- Isolate from mains before installation or dismantling work, as well as for fuse changes or post installation modifications.
- Observe the prescribed accident prevention and safety rules for the specific application.
- Before putting into operation check if the rated voltage for the unit conforms with the local supply voltage.
- Emergency stop devices must be provided for all applications. Operation of the emergency stop must inhibit any further uncontrolled operation.
- **The electrical connecting terminals must be covered!**
- **Earth bonding must be tested for integrity after installation.**

Specified Use

The units described herein are electrical controllers for installation in industrial plant. They are designed for controlling vibratory feeders.

Contents

Technical safety instructions for the user	2
Contents	3
1.0 General	4
2.0 Function	5
2.1 Track control	5
2.2 Operating with two speeds (2 set points for coarse/fine switching)	6
2.2.1 Time delayed change-over to 2nd setpoint	6
2.3 Control inputs and output	6
2.3.1 Enable input	6
2.3.2 Sensor input for track control	6
2.3.3 External set point	6
2.3.4 Output status relay	6
2.3.5 Ready relay	6
2.3.6 Temperature relay (only 8A - Version)	6
2.4 Display	6
3.0 Construction	7
4.0 Technical Data	7
5.0 Ordering Codes (Standard controller)	7
6.0 Declaration of Conformity	7
7.0 Settings	8
8.0 Control elements	9
8.1 Settings	9
9.0 Commissioning	10
9.1 Assembling position	10
9.2 Preliminary steps	10
9.2.1 Important points	10
9.2.1.1 Operating frequency of the feeder coil	10
9.2.1.2 Measurement of the output voltage and current	10
9.3 Putting the equipment into operation	11
9.4 Switch-on frequency of the power supply	11
10.0 Setting Instructions	12
10.1 User adjustment of throughput	12
10.2 Tuning the feed system	12
10.2.1 Feeder settings	12
10.2.2 Track control	13
10.2.3 Sensor time out	13
10.2.4 Set point source	13
10.2.5 Pulse feed	14
10.2.6 Regulation mode	14
10.2.6.1 Instructions for using regulation mode	15
10.2.6.2 Mounting the accelerometer	15
10.2.6.3 Relationship between acceleration and amplitude	17
10.2.6.4 Instructions for setting up the controller in regulation mode	17
10.2.6.5 Determining the resonant frequency	17
10.2.6.6 Optimising controller in regulation mode	18
10.2.6.7 Displays	18
10.2.7 Display actual current and frequency	19
10.2.8 Save selected parameters	19
10.2.9 Recall user or factory settings	19
10.2.10 Hide parameter menus	19
11.0 Error messages / ERROR reset	20
12.0 Connection diagrams	21
12.1 Connections for 16/32A versions	21
12.2 Connections for 8A versions	22
13.0 Dimensions	23
13.1 Dimensions of 16/32 A - Version	23
13.2 Dimensions of 8 A - Version	24
13.3 Mounting distance	25
A 1.0 Service appendix	26

1.0 General

The REOVIB MFS 268 range comprises special, adaptable controllers for use with vibratory feeders. The units generate an output frequency, to drive feeders, that is independent of mains frequency and so exact tuning with springs is not necessary. The feeders also run quieter because of the sinusoidal output signal. The adjusted output frequency corresponds to the mechanical vibrating frequency of the feed system. The optimum frequency setting for a feeder can be determined manually or automatically in regulation mode. Depending on the version, the controller can be used in regulation mode, working in conjunction with an accelerometer fitted to the feeder, to operate at resonant frequency. In this way a constant component feed rate that is unaffected by load changes can be achieved. In regulation mode the vibrating frequency is also dynamically adjusted to compensate for resonant frequency changes caused by load changes. In normal operating mode (without accelerometer) the feeder remains constant at the set frequency. In both operating modes the feeder throughput is determined by the output voltage level.

Notable Features:

- Adjustable output frequency, independent of mains frequency
- Adjustable minimum and maximum limits for the frequency range
- Adjustable current limit for the maximum coil current
- Constant feeder throughput irrespective of mains fluctuations
- Regulation control, with independent frequency search (resonance)
- On/Off status relay
- Track control
- 24 VDC output for operating a solenoid e.g air valve
- Four user setting memory locations
- Optional: Fieldbus systems (Profibus-DP, CAN-Bus, DeviceNet, EtherCAT, EtherNet-IP or PROFINET).

2.0 Function

The unit is set up by using the touch panel on the front plate (buttons and LED display). All settings can be made by using the touch panel and a series of menus. The various parameters can be selected by entering operator codes. A fuller description of the parameters can be found in the section on settings. Alternatively, the feeder throughput can be adjusted by using an external potentiometer, an external voltage signal 0...10 V, DC or a current signal 0(4)...20 mA (the chosen option must be selected in menu 003). A relay with potential free contacts is provided for feeder status indication and this operates in conjunction with the feeder enable signal. Terminals for these contacts can be found inside the controller. During normal operation the set point is displayed as a percentage in the LED window. In the programming mode the selected dimension, as described in the setting up instructions, is shown. Changed settings can be stored by leaving the programming mode or automatically saved by not pressing a key for a period of 100 seconds.

The control units can provide a frequency range from 5...150 Hz, which can be limited by adjustable, upper and lower frequency limits. The usable adjustment range cannot exceed a ratio of 1:4, i.e. the upper frequency limit cannot be more than four times the lower frequency limit. It is possible to have a narrower setting of the limits and this provides a margin of safety against too wide a difference in the vibrating frequency.


The maximum output current drawn by the coil can be determined by integrated current limiting. Critical parameters such as the current limit and vibrating frequency range are held under a special service menu. This menu cannot be accessed through the normal menu structure and an additional code number has to be used to gain access. This prevents unauthorised adjustment of these sensitive parameters.

An interface option can be used to provide Fieldbus systems (Profibus-DP, CAN-Bus, DeviceNet, EtherCAT, EtherNet-IP or PROFINET) connection.

2.1 Track control

The output can be switched ON and OFF from a track component sensor, using internal, adjustable time delays (ton and toff).

The queue of components rises above and drops below the track sensor position. The controller



output switches on when the sensor cannot detect product and a switch-on time delay has elapsed. The output is switched off when product is detected and a switch-off time delay has elapsed (FULL displayed in the LED window). Gaps in the product feed cause resetting of the time delay. The time will always be precise from the last or first component, respectively. The ON and OFF time delays are set in the programming menu. The first decimal point in the display blinks to indicate that an internal timer is running.

An additional “**Sensor-Time-out**” timer is started when the feeder switches on. This can be set (30...240 sec.) to switch off the feeder if no product is sensed in the time out period. The status relay indicates that the feeder is not running and the LED window displays ERROR and SE alternately. This function is optional and must be selected in the Track Settings Menu with function E.E.n. = 1.

2.2 Operating with two speeds (2 set points for coarse/fine switching)

Coarse/Fine control can be used instead of track control (Menu C 003). The second set point is activated through the same sensor input that is used for track control. Either contacts or a 24 VDC signal can be used to change the set point from coarse to fine. The second set point is activated, immediately, by applying a 24 V signal. (The track control function is invalid)

2.2.1 Time delayed change-over to 2nd setpoint

Using switch "S.2.d" in Menu C 003 it is possible to enable a time-delayed change-over to the 2nd setpoint.

2.3 Control inputs and output

2.3.1 Enable input

External switch or 24 VDC signal voltage.

External control function to switch the power output ON or OFF e.g. Networking of several controllers from a central PLC.

2.3.2 Sensor input for track control

Sensor for monitoring the queue of components on the track or an input for switching to the second setpoint 24 VDC (PNP).

2.3.3 External set point

The feeder amplitude set point can be provided from an external, analog 0...10 V, DC, 0(4)...20 mA, or a 10 kR Potentiometer. Parameter ESP in Menu C003 must be set to 1, for an external set point source to be used.

Setting the minimum output value when external set point = 0:

Before changing the ESP parameter to accept an external set point source, the minimum value can be adjusted by using the cursor keys, on the front panel, and this will remain when the ESP is changed over from 0 to 1.

2.3.4 Output status relay

Status-Relay contact 250 V/1 A (changeover). Relay closes when the feeder is running – the relay opens when there is no enable signal or a fault displayed.

2.3.5 Ready relay

With parameter "r.b." set to I it is possible to configure the internal status relay to a ready relay, which indicates exceeded current and voltage limits and also fault conditions like "Error OU".

Using the status relay function ("r.b." = 0) the relay switches when the power output is enabled and no fault is present.

2.3.6 Temperature relay (only 8A - Version)

To activate the temperature relay-function the parameter "r.b" in Menu: "C003" must be set to I.
Change-over contacts: 26,27,28.

2.4 Display

Initialisation phase, when supply voltage is connected (left decimal point blinks).

Normal Mode: The throughput set point is displayed

Output switched off using the '0' button

Unit inhibited by the enable input

Output switched off by the track control sensor

Under voltage, input voltage is too low.

3.0 Construction

- Touch panel with display
- Terminals for electrical connections
- Screw hole fixings for mounting

4.0 Technical Data

Model Type	MFS 268 / 32A	MFS 268 / 8A	MFS 268 / 16A
Supply voltage	1 x 115/230 V +/- 10 %, 50/60 Hz	3 x 400 V +/- 10 %, 50/60 Hz	
Output	0..95/205 V	0..360 V	
Output current	Max. 32 A	Max. 8 A	Max. 16 A
Recommended * Protection	16 A Anti-surge Type D current trip device		
Enable	24 V, DC input (connect to internal 24 V reference)		
Status/-Ready relay	Change-over contacts, 250V, 1 A		
Temperature switch input and Temperature relay	Change-over contacts, 250V, 1 A (only 8A - Version)		
Switch-on frequency of the power supply	wait 5 seconds until resetting the power supply		
Sensor supply	24 V, DC, 100 mA		
Sensor type	PNP output		
Operating temperature	0...45 °C		
Storage temperature	-10..80 °C		
Altitude	1000 m 0,5 % rated current reduction for each additional 100 m		

* The units are provided with switch-on, current damping. However it is still possible that some internal capacitor, energising, current spikes will be generated, especially when several units are switched on simultaneously. Therefore, fuses and overload trips should have anti current surge characteristics.

5.0 Ordering Codes (Standard controller)

Type	Order Code	Construction
REOVIB MFS 268 / 32A – IP20	621770	115/230 VAC, 32 A , Panel mounting with track control and accelerometer regulation
REOVIB MFS 268 / 8A – IP20	621779	3 x 400 VAC, 8 A , Panel mounting with track control, accelerometer regulation and temperature relay as to protect the magnets.
REOVIB MFS 268 / 16A – IP20	621775	3 x 400 VAC, 16 A , Panel mounting with track control and accelerometer regulation

6.0 Declaration of Conformity

We declare that these products conform with the following standards and directives:

Directives:

2014/30/EU EMC
2014/35/EU LVD
2011/65/EU RoHS

Standards:

EN 61000-6-4:2007 +A1:2011; EN 61000-6-2:2005
EN 50178:1997



REO AG, D-42657 Solingen

7.0 Settings

After checking the correct operation of the controller in conjunction with the vibratory feed system it is advisable to restrict the user to feeder throughput settings only.

Setting the feeder throughput:

Press the P key twice and adjust the throughput with the cursor keys (Code C. 000).

The following variable parameters are available for setting up the feed system

Parameter:		Display	Factory setting:	Entry Code:
Vibratory feeder				
• Amplitude (throughput))	0...100 %	A.	0 %	000, 002, 020, 096
• Maximum control limit (U_{max})	5...100 %	P.	90 %	008, 020, 096
• Vibrating frequency	30...140 Hz (5...150 Hz)	F.	100 Hz	008, 020 040, 096,
• Soft start ramp up	0...60 Sec.	/.	0.1 Sec.	020, 096
• Soft stop ramp down	0...60 Sec.	\.	0.1 Sec.	020, 096
• Switch to external set point	0 / 1	E.S.P.	0	003
• Set point 0(4)...20 mA	0 / 1	4.20	0	003
• Coarse / Fine control	0 / 1	S.P.2.	0	003
• Second setpoint delay	0 / 1	S.2.d	0	003
• Invert enable	0 / 1	-En.	0	003
• Status / ready relay (+Temperature relay only at 8A - Version)	0 / 1	r.b.	0	003
• Pulse feed	0 / 1	HOP.	0	064
• On time delay (only if HOP. = 1)	0...60 Sec.	H.	1.0 Sec.	064
• Off time delay (only if HOP. = 1)	0...60 Sec.	h	1.0 Sec.	064
• Invert hopper sensor (not active)	0 / 1	-Ho.	0	064
Regulation (with sensor)				
• Switch to regulation	0 / 1	ACC.	0	008
• P characteristic	0...100	P.A.	40	008
• I characteristic	0...100	I.A.	100	008
• Automatic frequency control	0 / 1	A.F.C	0	008
• Start automatic frequency search		A.F.S.		008
Track control				
• Switch on time delay	0...60 Sec.	I.	1.0 Sec.	007, 167
• Switch off time delay	0...60 Sec.	O.	1.0 Sec.	007, 167
• Invert sensor	PNP / PNP - invert	-SE.	PNP	007, 167
• Sensor Time-out	0 / 1	E.En.	0	015, 167
• Sense time delay (Sensor Time-out)	1...240 Sec.	E.	180 Sec.	015, 167
• Switch off time air valve	0...60 Sec.	A.i.	4 Sec.	015
Service				
• Display actual output current		i.		040
• Display actual frequency		F.		040
• Save user settings		PUSH.		143
• Recall factory settings		FAC.		210
• Recall user settings		US.PA.		210
• Hide programming menus	0 / 1	Hd.C.	0	117
• Hide set point adjustment	0 / 1	di.S.	0	137
• Display software version				001

8.0 Control elements


8.1 Settings

The six buttons and a LED display found in the front panel, are used for operating and setting up the unit. All operating methods and adjustable parameters can be set up through this panel.

The “I” and “O” buttons are used for switching the unit ON and OFF, however, these do not provide mains isolation, they simply inhibit the power semiconductors

The “P”, “F” and “Cursor Buttons” are used for parameter adjustment. Parameters are set by using menu controls which are called up by entering operator codes. The functions are described in greater detail in the section on setting instructions.


The display value can be increased or decreased by units, or tenths of units, by a short press of the cursor buttons. Holding the buttons down will cause the display to change in units of ten.



To prevent accidental or unauthorized adjustment the adjustment parameters, in the user menus, are protected. A code must be entered to open the user menus. There are different pass codes for each function group.

Setting adjustments are automatically saved upon leaving the programming mode or if no button is pressed for a period of 100 seconds.

All setting routines are commenced by pressing the programming button “P”. The following diagram should clarify the sequence in which keys are pressed:



1. Press the “P” key.
2. Select the code number with the cursor keys.
3. Press the “P” key. This displays the first menu point. The required menu point can be found by repeatedly pressing the “P” key (scrolling).
4. The value in the menu point can be changed with the cursor keys.
5. Scroll to the next menu point or to the end of the menu, which returns the display to the set point value, by pressing the “P” key. To exit the menu and return back to the normal display, quickly depress the “P” key for 5 seconds.
6. To return back to the previous position in the menu, press the “F” key.

9.0 Commissioning

9.1 Assembling position



Please fasten the devices on a vibration-free underground and take care for sufficient air circulation.

9.2 Preliminary steps

- Check that the unit is correct for the local mains supply (rating plate information) and that it is correctly rated for the feed system.
- Connect the controller according to the connection diagram
- When applications with frequently on and off cycles are required, use the intended enable input. It is prohibited to open the current circuit with a switch or a contactor while the feeder is running.

9.2.1 Important points



Using the control units described in this document, it is possible to adjust the feed system that it runs in resonance. In this condition it is possible to obtain excessive output for a very low set point setting. Therefore extreme care should be taken to avoid causing damage to the drive coil, through hammering.

In practice it is not possible to run at resonant frequency without accelerometer feedback because the system would be unstable and uncontrollable. The system must be set safely off resonance i.e. either above or below the natural frequency.

Resonant frequency: Depending on the spring and mass design of the feeder system it is possible to have resonance at more than one frequency. These additional resonance points are multiples of the main frequency. For this reason in critical situations it is possible that the automatic frequency search will not find true resonance and in such cases the natural frequency must be determined manually.

9.2.1.1 Operating frequency of the feeder coil

It is possible that the current flowing through the coil will increase for a small frequency adjustment and so this should be checked with a true RMS instrument for each new application as well as monitoring the coil for heat build-up.

The coil should be designed for the correct operating frequency to prevent excessive current draw and the consequential overloading of the coil.

9.2.1.2 Measurement of the output voltage and current

The voltage and current cannot be measured with a regular instrument because the controller output uses an electronic inverter with a pulse width modulation signal. An effective measuring instrument such as a moving iron meter (analog) must be used. It is recommended that an analog instrument is used rather than an electronic multi-meter which will give a misleading reading.

9.3 Putting the equipment into operation

1. Establish the vibrating frequency.
2. Establish the power of the feed system (maximum permissible current draw).

For a new feeder where settings are unknown: (see also comments below)

Without connecting the feeder, select parameter FAC in menu C210 (reset factory settings), press the cursor key to reset (SAFE) and press the P key to leave the menu. The factory settings are listed in the table in section 7, headed settings

! Comments !

It is possible that a special parameter set, for a machine manufacturer, has been pre-stored under a user code and these can be recalled. In such instances specific machine settings will be loaded and so the next steps are not relevant.

Basic settings:

- Connect feeder.
- Set frequency (refer to feeder data sheet). Menu C096 parameter F.
- Check current limit (refer to feeder data sheet). Menu C040 parameter I (shows the current limit as a percentage of maximum). If applicable use service menu for setting.
- Increase set point, observe feeder, check running.
- Increase set point to maximum and check if power needs limiting (hammering). If necessary adjust the limit as follows:-
- Adjust set point to zero
- Set parameter P (maximum limit) in Menu C096 to 50
- Adjust set point A to 100%.
- Increase the maximum limit P from 50% until the required amplitude is reached.
- The full set point range of 0...100% can now be used.

Additional settings e.g. soft start, time delays etc. can be set to suit the particular equipment.

Determining the output frequency (vibrating frequency)

It is essential that the output frequency is adjusted with the set point set at a low frequency, otherwise on hitting the resonant frequency it is possible to achieve a high amplitude with a low output voltage. An analog, effective value, current indicating unit (moving iron meter) must be connected into the output circuit.

Resonant is reached when there is a maximum amplitude for a minimum output current.

To achieve a stable feed system there must be an offset between the vibrating frequency and resonance (approx. 1...2Hz). This offset must be determined by the user because different feeders have different running characteristics.


9.4 Switch-on frequency of the power supply

Please wait about 5 seconds until resetting the power supply to reduce not the efficiency of the internal inrush current limiter.

10.0 Setting Instructions

10.1 User adjustment of throughput


Code C. 000



Feeder amplitude set point
0...100 %

Running mode

A further set point code can be found under C002
(for use in coarse/fine operation)



Feeder amplitude set point
0...100 %


2nd Feeder amplitude set point
0...100%
(only if "SP.2. = I)

Running mode

10.2 Tuning the feed system

10.2.1 Feeder settings

Code C. 020, 096



Feeder amplitude set point
0...100 %

Max. output 100...5 %

Vibration frequency [Hz]

Soft start 0...60 Sec.

Soft stop 0...60 Sec.


Running mode

Setting the maximum limit

1. Adjust set point to zero
2. Set parameter P (maximum limit) to 50.
3. Adjust set point to 100%
4. Increase the limit P from 50% until the required amplitude is reached
5. The full set point range of 0...100% can now be used


10.2.2 Track control

Code C. 167, 007




10.2.3 Sensor time out

Code C. 015




10.2.4 Set point source

Code 003




10.2.5 Pulse feed

Code C. 064



10.2.6 Regulation mode

Code C. 008





10.2.6.1 Instructions for using regulation mode

- An accelerometer e.g. SW 10 must be fitted to the vibratory feeder in order to run in regulation mode. The accelerometer should have a frequency range corresponding to that of the feeder.
- **All** vibration signals, that are picked up by the accelerometer, are used by the regulator circuit. Stray signals generated by neighbouring machinery, a flimsy accelerometer mounting, or an unstable support frame, can cause incorrect regulation to occur. It is especially important to ensure that there are no external influences, of this type, during the automatic frequency search routine.
- **Resonant frequencies:** It is possible to have several vibrating frequencies, where resonance occurs, depending on the springing and masses of the system. The additional resonant points are at multiples of the dominant resonant frequency. Under extreme circumstances the automatic frequency search may be unable to differentiate between these frequencies and so in these instances the frequency must be set manually.


10.2.6.2 Mounting the accelerometer

The accelerometer should generate signals for the movement and acceleration of the feeder, which are fed back to the regulator circuit of the control unit. Therefore it is very important that no other extraneous vibration signals are picked up by the sensor




The sensor should be positioned, that it moves in the same direction as the feeder, ideally in the same plane as the springs. It should be fitted on a solid block that will not generate vibration signals.

The sensor cable need to be fixed with a cable clamp to avoid damage of the cable.



In regulation mode the magnitude of the output signal has a direct effect on the maximum amplitude of the feeder.

On bowl feeders it is advisable to fit the sensor as near as possible to the outside diameter and in this position it will be subjected to the greatest movement





The control range of the set point will be considerably reduced when the sensor signal is weak.

s = deflection

Mounting position 1 = small deflection
Mounting position 2 = large deflection

Bowl feeder example



1. small amplitude because sensor is mounted vertically.

2. larger amplitude because sensor is mounted in the same plane as the springs.

Linear feeder example

The controller, together with the sensor fitted on the feeder, produce a feed back loop, whereby the signal generated from the sensor determines the control range of the set point i.e. the regulator controls the feeder so that the effective value (feeder power or intensity of vibration) relates to the provided set point value. Because the effective value is dependent on the feeder (frequency, acceleration and amplitude) and in addition depends on the mounting position of the sensor, the regulator must be adapted to suit the output control range.

This is achieved by using the parameter P in Menu C 008. The measured sensor signal range is adjusted by changing this value. In most instances a value of less than 100 must be entered, so that the set point can reach 100% or can go as high as possible.

When it is not possible to achieve an acceptable range the accelerometer should be mounted in the location which gives the greatest movement (see the bowl feeder example).

The importance of scaling this value is demonstrated when, for example, a feeder takes a very long time to ramp up, after it has been switched on.

10.2.6.3 Relationship between acceleration and amplitude

The sensor measures the momentary acceleration of the feeder. It generates a sinusoidal output voltage signal. The acceleration gets higher as the frequency increases. The sensor signal is greater for a higher frequency and lower amplitude than for a low frequency with a higher amplitude.

<p>Acceleration</p> $a = \omega^2 s \quad \text{where} \quad \omega = 2 \pi f$ <p>In practice the acceleration is influenced by gravitational force and the applied amplitude is measured in mm and so this gives the following formula:</p> $a[g] = \frac{2^2 \pi^2 f^2 [Hz]^2 s_n [mm]}{9,81 \cdot 2 \cdot 10^3} = \frac{f^2 [Hz]^2 s_n [mm]}{497}$ <p>a[g] = Acceleration (with respect to gravitational acceleration of 9.81 m/s²) S_n[mm] = Applied amplitude</p>	<p>In practice where 497 is approximated to 500 this gives, for example:</p> <p>1. Vibrating frequency 50Hz Amplitude 3mm</p> $a = \frac{50^2 \cdot 3}{\approx 500} = 15 g$ <p>Or</p> <p>2. Vibrating frequency 33Hz Amplitude 5mm</p> $a = \frac{33^2 \cdot 5}{\approx 500} = 10,89 g$
--	---

Using an accelerometer with an output signal of 0.3 V/g the sensor generates a peak voltage of 4.5V for a peak acceleration of 15g (Example 1), corresponding to a 3.18V RMS value.

Example 1: => 15 g => 4,5 V => 3,18 V_{eff}.

Example 2: => 11 g => 3,3 V => 2,33 V_{eff}.

Because of the vastly different acceleration values of various feeders there is a big difference in the feed back signals, which makes scaling necessary.

10.2.6.4 Instructions for setting up the controller in regulation mode

Connect control unit

Install sensor and connect to controller

10.2.6.5 Determining the resonant frequency

Manual setting of the vibrating frequency

It is essential that the output frequency is adjusted with the set point set at a low frequency, otherwise on hitting the resonant frequency it is possible to achieve a high amplitude with a low output voltage. An analog, effective value, current indicating unit (moving iron meter) must be connected into the output circuit. **Resonant frequency is reached when there is a maximum amplitude for a minimum output current.**

Automatic frequency search

- The feeder should be empty for a frequency search
- Adjust the set point to zero
- Select regulation mode (Menu C 008, Parameter ACC = I)
- The optimum frequency of the feeder is found, automatically, by initiating the frequency search (Menu C 008, Parameter A.F.S.). When this has been found the controller resets the set point back to its original value (0).

10.2.6.6 Optimising controller in regulation mode

Setting the control range

1. In Menu C. 096 set parameter P (Max Limit) to 50 %
2. Set A (Feeder throughput) to 100%
3. Increase limit P from 50% until the required maximum feeder throughput is achieved

The full set point adjustment range of 0...100% can now be used

Optimising regulation: For unwanted feeder oscillation (hunting) or inadequate feedback regulation for load changes

The response of the regulation circuit can be adjusted in menu C008 using the parameter PA (Proportional characteristic or circuit gain) and IA (Integral characteristic)


In menu C008 reduce PA until the oscillations are reduced

Parameter IA should be set to at 100 if possible


10.2.6.7 Displays



1. The maximum output power of the controller has been reached.
The feedback signal from the sensor (acceleration) is too low in comparison with the set point. Reduce parameter P in Menu C096 or C008.
2. The maximum current setting has been reached.



The feedback signal from the sensor (acceleration) is too high.




Changing display:
The regulator oscillates too quickly.
Reduce parameter PA in Menu C008..




10.2.7 Display actual current and frequency

Code C. 040




10.2.8 Save selected parameters

Code C. 143




10.2.9 Recall user or factory settings

Code C. 210



10.2.10 Hide parameter menus

Code C. 117



11.0 Error messages / ERROR reset

Errors are indicated by an alternating code and ERROR display

Overload limit



Output level exceeded e.g. incorrect frequency setting, coil air-gap too wide.

Short circuit trip



Faulty coil, short circuit or defective cable..

Over voltage

Supply voltage too high or back EMF from the coil at lower frequencies.



Current spike limit

Frequency set too low for installed coil or frequency altered too rapidly during setting up.



Sensor fault (only when regulation mode is selected)
Accelerometer not working or faulty.



ERROR Reset through Menu C009

Sensor time out

After sensor time out has elapsed



ERROR Reset is achieved by pressing touch panel keys 0 or I during normal operation or by using Menu C009.

In the event of an error check that this is not caused by incorrect wiring or cable faults. The error message, ERROR ACC, can also occur if regulation mode is chosen (in Menu C008) and an accelerometer is not connected, for example.

Reset the error in the following manner:


ERROR RESET




Frequently appearing Errors, which are not described in this chapter, should be reported to the manufacturer.

12.0 Connection diagrams


12.1 Connections for 16/32A versions



Control connections




Recommended method of terminating screen of output cable



The output cable to the feeder must be screened to conform with EMC regulations.

Spring-clamp for screen connection of output and accelerometer cables.

12.2 Connections for 8A versions



Temperature relay optionally available.
For more information, see item 5 on page 7 in this manual.

A 1.0 Service appendix

ATTENTION !

The settings described in this section relating to the service menu are intended for use by skilled persons because the functions and limits of the feed system can be greatly influenced by their adjustment

It is the responsibility of the supplier of the equipment to decide whether this information should be released or restricted for use by service engineers only.

The service menu cannot be accessed through the normal menu structure. It can only be enabled by using a special key code.

Service Menu

The critical parameters, current limit and user adjustable frequency range are held in a separate service menu. This menu cannot be reached through the normal menu structure and must be enabled by using an additional code number. This prevents the unauthorised changing of these sensitive parameters

- **Current Limit** – Protects the coil against overload.
The output current limit is set to the maximum current rating of the coil.
- **Current regulator**
A speed optimization in the switch-on situation of the conveyor can be reached
- **Frequency limits** – Protection against unhealthy operation.
The vibrating frequency limits available to the user are fixed.
- **Output voltage limit**
The output voltage limit allows 200V magnets to be used on a 3x 400V supply without damage.


Parameter:		Display	Factory setting:	Entry code:
• Enable service menu	0 / 1	En.S:	0	127
• Adjust current limit	0...100 %	I.	100	040
• Current regulation On/Off	0 / 1	E.Fu.	0	040
• Current regulation proportional value	1..100 %	P.I.	60	040
• Current regulation integral value	1..100 %	I.I.	80	040
• Set lower frequency	5...150 Hz	F.L.	35	040
• Set upper frequency	6...150 Hz	F.H.	140	040
• Limit output voltage 110 V	0..100	P.L.	100	040

Frequency adjustment range

The control unit is supplied with a maximum frequency range of 5...150 Hz. Using an adjustable under and over frequency limits, the user range (parameter F) can be restricted to a maximum ratio of 1:4. In regulation mode, this restricted frequency range has great importance because it assists with the accurate determination of the measurement signals from the accelerometer. During the automatic frequency search a maximum sweep range of 1:4 is possible. The lower (FL) and upper (FH) frequency limits restrict the range. A narrow setting of the limits of less than 1:4 is possible and also advisable because this ensures that widely different changes of the frequency cannot occur when the user is setting up the system.

The range of the automatic frequency control (AFC) is also limited by these settings.

A practical setting is +/- 20 % of resonance.



1. Set lower frequency limit.
2. Set upper frequency limit.

Current limiting

The current limit is used to set the controller for the rated current of the coil I_M . The current limit I_{MAX} is set by using parameter I. The displayed setting is expressed as a percentage of the controllers rated current I_N (100 % corresponds to the units rated current).

$$I_{MAX} = \frac{I_M \cdot 100}{I_N}$$

To protect the coils the current limit must be set to the rated current for the coil(s) I_M .

When several coils are connected in parallel the coil current is the sum of all individual currents.


Current regulator

To reduce the response delay of the vibratory feeders due to the built-in frequency converter current control, can use the switch "E.Fu." the current controllers are disabled. And there is an over-current and peak-current function of the set current limit I_{max} available. However, it is recommended to leave the current regulator on and disable it only for time-critical applications.

Furthermore, it is possible to adapt the control parameters proportional and integral component of the current regulator to the application. This may also be a speed optimization, without compromising on the current control can be performed.

Enable Service Mode


The actual service menu is accessed by opening the service mode.



The normal service menu, containing the output current and frequency limit settings, is accessed by opening the service mode.

Service menu

Code 040



After making adjustments the service mode must be closed again!



■ REO AG

Brühler Straße 100 · D-42657 Solingen
Tel.: +49 (0)212 8804 0 · Fax: +49 (0)212 8804 188

E-Mail: info@reo.de
Internet: www.reo.de

Divisions:

REO Vibratory Feeding and Power Electronics Division

REO Vibratory Feeding and Power Electronics Division
Brühler Straße 100 · D-42657 Solingen
Tel.: +49 (0)212 8804 0 · Fax: +49 (0)212 8804 188
E-Mail: info@reo.de

REO Train Technologies Division

REO Train Technologies Division
Erasmusstraße 14 · D-10553 Berlin
Tel.: +49 (0)30 3670236 0 · Fax: +49 (0)30 3670236 10
E-Mail: zentrale.berlin@reo.de

REO Drives Division

REO Drives Division
Holzhausener Straße 52
D-16866 Kyritz
Tel.: +49 (0)33971 485 0 · Fax: +49 (0)33971 485 90
E-Mail: zentrale.kyritz@reo.de

REO Medical and Current Transformer Division

REO Medical and Current Transformer Division
Schulholzinger Weg 7 · D-84347 Pfarrkirchen
Tel.: +49 (0)8561 9886 0 · Fax: +49 (0)8561 9886 40
E-Mail: zentrale.pfarrkirchen@reo.de

REO Test and PowerQuality Division

REO Test and PowerQuality Division
Brühler Straße 100 · D-42657 Solingen
Tel.: +49 (0)212 8804 0 · Fax: +49 (0)212 8804 188
E-Mail: info@reo.de

PRODUCTION+SALES:

- **India**
REO GPD INDUCTIVE COMPONENTS PVT. LTD
E-Mail: info@reogpd.com · Internet: www.reo-ag.in
- **USA**
REO-USA, Inc.
E-Mail: info@reo-usa.com · Internet: www.reo-usa.com

SALES:

- **France**
REO VARIAC S.A.R.L.
E-Mail: reovariac@reo.fr · Internet: www.reo.fr
- **Great Britain**
REO (UK) Ltd.
E-Mail: main@reo.co.uk · Internet: www.reo.co.uk
- **Italy**
REO ITALIA S.r.l.
E-Mail: info@reitalia.it · Internet: www.reoitalia.it
- **Poland**
REO CROMA Sp.zo.o
E-Mail: croma@croma.com.pl · Internet: www.croma.com.pl
- **Spain**
REO ESPAÑA 2002 S.A.
E-Mail: info@reospain.com · Internet: www.reospain.com
- **Switzerland**
REO ELEKTRONIK AG
E-Mail: info@reo.ch · Internet: www.reo.ch
- **Turkey**
REOTURKEY ELEKTRONIK San. ve Tic. Ltd. Şti.
E-Mail: info@reo-turkey.com · Internet: www.reo-turkey.com
- **China**
REO Shanghai Inductive Components Co., Ltd
E-Mail: info@reo.cn · Internet: www.reo.cn